


Quick Release Stainless Steel Bracket For Flojet G57 Air Pump

MODEL # 226095BRKT

OVERVIEW

Designed by Lafferty specifically for use with the Flojet G57 air pump, the Lafferty Quick Release Bracket allows easy removal and replacement of the air pump, without tools.



Adds a quick-release capability to any Flojet G57 pump installation

- Included as a standard component in most Lafferty systems with a Flojet G57 Air pump (for example, FPS Transfer Systems; Liberty and Liberty LF foamers and sprayers).
- Bracket consists of a single, laser-cut stainless steel plate with precision bends and a riveted top clamp.
- Includes mounting tabs with pre-drilled holes
- Clamp securely holds pump in place while allowing quick release without tools

To install pump

- Place bottom lip of pump against base of bracket, behind the metal tabs
- Push top of pump back against the bracket until the top clamp snaps firmly over the lip of the pump

To remove pump

- Grasp the pump firmly with one hand
- Press up on the top clamp to release the pump
- Gently pull the top of the pump forward to clear the clamp
- Lift the pump upward and slightly forward away from the bracket

Other Popular Lafferty Accessories

- Stainless Steel Chemical Jug Racks (#224195 - #224216)
- Stainless Steel Hose Racks (#224140 - #224150)
- Polypropylene Drum & Tote Sticks (#491643 - #491654)
- Jug Lid (1&5 Gallon) with Suction Tube (#709101)
- Metering Tip Driver (#443790)