

# Lafferty Equipment Manufacturing, Inc. Installation & Operation Instructions

Model # 709101-5 · 5-Way Safe Flow™ Lid for 1 Gallon Jugs

## REQUIREMENTS / SPECIFICATIONS

<b>Chemical Container</b>	Fits most 1 gallon jugs (~38mm thread OD) <i>Alternate Thread Styles/Sizes Available Upon Request</i>
<b>Unit with Suitable Check Valve</b>	Mixing Stations and units with 491402 / 491401 or other spring-loaded check valves



**Lafferty**  
EQUIPMENT MANUFACTURING INC.

[www.laffertyequipment.com](http://www.laffertyequipment.com)

501-851-2820

**WARNING! READ ALL  
INSTRUCTIONS BEFORE  
USING EQUIPMENT!**



## OVERVIEW

Safe Flow Lids™ provide safe and convenient dispensing of chemicals from 1 gallon containers. The threaded lid keeps out contaminants, reduces odors and prevents chemical splashing and spillage. These unique, heavy-duty, machined polypropylene lids attach to chemical suction tubes with a 1/4" hose barb and can be quickly unscrewed and attached to another container or easily removed and stored. Includes a strainer and suction assembly to place inside the chemical container. Available with various lid threads.





PREVENTIVE MAINTENANCE: When the unit will be out of service for extended periods, place chemical tube(s) in water and flush the chemical out of the unit to help prevent chemical from drying out and causing build-up. Periodically check and clean chemical strainer and replace if missing.

